


## Analysis and Report

This section will compare transmission times obtained from sending packets of various sizes using UDP and TCP.




The diagram above shows the results obtained after sending 10 and 100 packets of various packet sizes in UDP.

We can see that as packet size increases:

- Transmission time of data increases
- Packet Loss percentage increases

The transmission times range from 2ms up to 5ms when sending 10 packets, and 23ms to 35ms when sending 100 packets.



The diagram above shows the results obtained after sending 10 and 100 packets of various packet sizes in TCP.

Similarly to UDP, as packet size increases, transmission time of data increases too. TCP, however, takes much longer to transmit data. The range for TCP's transmission times is 7ms to 23ms for sending 10 packets and 85ms to 105ms when sending 100 packets, almost four times as long as UDP.


## Conclusion

UDP is faster than TCP, but TCP is more reliable. As packet size increases, it is more likely for the packet to contain errors and be discarded in UDP.

TCP is better suited for applications that require high reliability; UDP is suited for applications that need fast transmission. An example for TCP would be file transfers and for UDP, gaming.

## Testing

### Selecting a file




## TCP Connection Established

C:\> Select Command Prompt			
TCP	127.0.0.1:53545	0.0.0.0:0	LISTENING
TCP	127.0.0.1:53545	127.0.0.1:64439	ESTABLISHED
TCP	127.0.0.1:56333	0.0.0.0:0	LISTENING
TCP	127.0.0.1:56334	0.0.0.0:0	LISTENING
TCP	127.0.0.1:56335	0.0.0.0:0	LISTENING
TCP	127.0.0.1:56336	0.0.0.0:0	LISTENING
TCP	127.0.0.1:64437	127.0.0.1:27015	ESTABLISHED
TCP	127.0.0.1:64439	127.0.0.1:53545	ESTABLISHED
TCP	192.168.0.10:139	0.0.0.0:0	LISTENING
TCP	192.168.0.10:7000	192.168.0.10:53810	ESTABLISHED
TCP	192.168.0.10:49441	13.89.184.238:443	ESTABLISHED
TCP	192.168.0.10:49487	142.232.230.30:443	FIN_WAIT_2
TCP	192.168.0.10:51909	52.43.202.10:443	ESTABLISHED
TCP	192.168.0.10:52464	157.55.170.113:5671	ESTABLISHED
TCP	192.168.0.10:53365	34.210.102.41:443	ESTABLISHED
TCP	192.168.0.10:53604	13.89.184.96:443	ESTABLISHED
TCP	192.168.0.10:53768	13.33.151.143:443	CLOSE_WAIT
TCP	192.168.0.10:53810	192.168.0.10:7000	ESTABLISHED
TCP	192.168.0.10:53812	40.121.213.159:443	TIME_WAIT

## UDP Connection Established

C:\> Select Command Prompt		
UDP	0.0.0.0:3544	*.*
UDP	0.0.0.0:3702	*.*
UDP	0.0.0.0:3702	*.*
UDP	0.0.0.0:3702	*.*
UDP	0.0.0.0:3702	*.*
UDP	0.0.0.0:3702	*.*
UDP	0.0.0.0:3702	*.*
UDP	0.0.0.0:5050	*.*
UDP	0.0.0.0:5353	*.*
UDP	0.0.0.0:5353	*.*
UDP	0.0.0.0:5353	*.*
UDP	0.0.0.0:5353	*.*
UDP	0.0.0.0:5353	*.*
UDP	0.0.0.0:5353	*.*
UDP	0.0.0.0:5355	*.*
UDP	0.0.0.0:7000	*.*
UDP	0.0.0.0:50532	*.*
UDP	0.0.0.0:50955	*.*
UDP	0.0.0.0:52484	*.*
UDP	0.0.0.0:52692	*.*
UDP	0.0.0.0:52693	*.*
UDP	0.0.0.0:53698	*.*
UDP	0.0.0.0:55233	*.*

## Sending Data Using TCP



The screenshot shows a Windows application window titled "Assignment 2" with a menu bar containing "Settings", "File", and "Start". A "Dialog" box is open, allowing configuration of network settings. The dialog has two columns of input fields. The left column is for "Client or Server" settings, and the right column is for "TCP or UDP" settings. The "Client or Server" column includes fields for "client" (text), "Port Number" (7000), and "Number of Packets" (10). The "TCP or UDP" column includes fields for "tcp" (text), "Packet Size" (1024), and "IP address" (192.168.0.10). At the bottom right of the dialog are "OK" and "Cancel" buttons.

Client or Server	TCP or UDP
client	tcp
Port Number	Packet Size
7000	1024
Number of Packets	IP address
10	192.168.0.10



OK Cancel



The screenshot shows the "Assignment 2" application window with the menu bar "Settings", "File", and "Start". Below the menu bar, the text "Received packet of size : 1024" and "Number of Packets: 10" is displayed.

Received packet of size : 1024  
Number of Packets: 10


## Sending Data Using UDP



## Data Saved to File

C:\ > Users > antho > source > repos > 4985A2 > Debug					Search Debug
Name	Date modified	Type	Size		
4985A2.exe	2/14/2018 2:57 AM	Application	123 KB		
4985A2.ilnk	2/14/2018 2:57 AM	Incremental Linke...	3,990 KB		
4985A2.pdb	2/14/2018 2:57 AM	Program Debug D...	4,772 KB		
input.txt	2/14/2018 1:40 AM	Text Document	5,994 KB		
tcp.txt	2/14/2018 3:00 AM	Text Document	11 KB		
udp.txt	2/14/2018 3:07 AM	Text Document	41 KB		

## State Chart



### Idle

Starting state of the program. Displays a simple GUI to the user.

- If user decides to upload a file, go to **File Selection** state
- If user decides to change Settings, go to **Settings** state
- If user wants to begin sending or receiving data, go to **Set Up Connection** state

### File Selection

Opens another GUI to allow the user to select a file to upload to a server. Selecting 'OK' will send the user back to the **Idle** state.

### Settings

Opens a dialog box for the user to enter in values for:

- Mode: Client or Server
- Protocol: TCP or UDP
- Port number
- Packet Size
- Number of packets to send
- IP address

Selecting 'OK' or 'Cancel' will send the user back to the **Idle** state.

### Set Up Connection

For TCP:

- Create a socket
- Client requests a connection
- Server Accepts Request

For UDP:

- Create a socket
- Both Client and Server bind to a local address

If set up is successful, go to either **Packetize Data** state or **Receive Data** state, depending on the mode

### Packetize Data

Breaks up the file specified by the user into packets of n Bytes, where n is a value specified by the user in the **Settings** state. Once the data has been broken up, go to **Send Packets** state.

### Send Packets

Send packets to a socket. When all packets have been sent or max number of packets has been sent, return to **Idle** state.

### Receive Data

If there is data in the socket, go to **Display Data** state and **Create and Write Data to File** state.

### Display Data

Display number of packets Received, as well as the size of the most recent packet received. Return to **Idle** state.



## Create and Write Data to File

Creates a file to save data. Return to **Idle** state.

## Pseudocode

### WinMain

- Initialize variables for creating window and opening files

- Create window

### WndProc

- Create WM\_SOCKET event handler

  - If WM\_SOCKET event triggered

    - Call ServerProc() or ClientProc()

- Create File Selector event handler

  - If File Selector event triggered

    - show window for file selection

- Create Settings event handler

  - If Settings button clicked

    - Show dialog box for settings

- Create Start event handler

  - If Start button clicked

    - Set up Connection for TCP/UDP

- Create WM\_PAINT event handler

  - Repaint the window every time a packet is received and display that value

### ClientProc

- Create Socket Information for socket if connected

- Listen for ready-for-write events

  - Packetize data received from file

  - Send data to socket

  - Calculate delay for sending

### ServerProc

- Accept a request for connection if requested

- Create Socket Information for accepted socket

- Listen for read events

  - If there is data in the socket

    - Retrieve data and send to file

    - Output data to the GUI

  - Clear Buffer

### Lowercase

- Loop through each character in the array

  - Change character to lowercase

### setDefaultSettings

- set default values for mode, protocol, port number, packet size, max packets, and IP address

### GetSocketInformation

- Look for socket in SocketInfoList

  - If SocketInfoList contains socket

Return socket

### CreateSocketInformation

Set Values for LPSOCKET\_INFORMATION struct of a socket

### FreeSocketInformation

Look for Socket in SocketInfoList

If SocketInfoList contains socket

Free Socket

### ToolDlgProc

Handle dialog box events for changing settings

### Delay

Subtract end time from original time and multiple by 1000

Subtract end milliseconds from original milliseconds

Add values together and return that value